

Rubber Tank Knee Pad for Harley Pan America 1250

VST-010103-008



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This Tank Knee Pad is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into “PARK”. Turn key to “OFF” position and remove from vehicle.

1. First clean the installation position of the motorcycle fuel tank sticker, and then wipe it again with the wet paper towel of the prepared adhesion promoter. Finally, peel off the release paper on the back of the fuel tank sticker, paste it on the fuel tank, as shown in the picture.



2. installation finished.

Rubber Tank Knee Pad for Harley Pan America 1250

VST-010103-008

