

Air Deflector for Harley Touring

VST-010103-035



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

These air deflectors are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. First, remove the side windshield of the original car. Then, install the new non-adjustable side windshield on your motorcycle. Lastly, fix the original car screws back (The other side is installed in the same way). Shows as the picture:



2. Finish installation.

